

Splice Operation

Turning splicer ON

Confirming splice, heater and operation modes

Cleaning coating or sheath of fiber

Placing protection sleeve over fiber

Stripping fiber

Cleaning fiber

Cleaving fiber

Loading fiber onto splicer

Splicing start automatically

Visual inspection on LCD during splice

Removing spliced fiber

Centering protection sleeve in tube heater

Centering spliced point in tube heater

Heating start automatically

Completed

- When splicing only standard SM fibers (ITU-T G.652), "SM AUTO" mode is recommended.
- When splicing different types of fibers, "AUTO" mode is recommended, but splice speed is slow.



- Hold lid firmly
- Free of any gel residue
- Make sure the stripped fiber is free of coating debris or contamination.
- Use only 99% or better purity alcohol.




- Hold this point firmly



Placing Fiber Holder

- Do not reverse Fiber Holder when placing onto splicer. Set in the direction which sees from the sheet key side and can read the name of a holder.





Note

- * Hold the fiber at edge of splicer body.
- ** Apply tension to the fiber until heater holds the fiber.

When using single holder


Adjusting the position of the fiber coating edge to holder edge





- When splicer indicates following message, splice loss may be high "Arc discharge is not stable. Electrodes should be stabilized to reform the arc discharge."
- Load prepared SM fibers onto splicer in order to stabilize electrodes. After completing it, re-splice fibers.
- When an altitude changes drastically, stabilizing electrodes must be executed before splicing.

How to use Keypad

<p>ON/OFF Key</p> <ul style="list-style-type: none"> • Power ON/OFF 	<p>X/Y Key</p> <ul style="list-style-type: none"> • Switch X/Y images 	<p>SET Key</p> <ul style="list-style-type: none"> • Execute Splice 	<p>ESCAPE Key</p> <ul style="list-style-type: none"> • Return to previous screen
<p>Open/Close Key</p> <ul style="list-style-type: none"> • Operation of a Wind Protector 	<p>ARC Key</p> <ul style="list-style-type: none"> • Arc 	<p>HEAT Key</p> <ul style="list-style-type: none"> • Heat Cancel • Operation of a lid 	<p>MENU Key</p> <ul style="list-style-type: none"> • Open Main Menu • Go to next page
<p>RESET Key</p> <ul style="list-style-type: none"> • Stop and back to Ready 	<p>UP/DOWN Key</p> <ul style="list-style-type: none"> • Move cursor • Change value 	<p>ENTER Key</p> <ul style="list-style-type: none"> • Enter of value 	



LED

- **Turning ON**
Press  key until **green** LED turns on.
- **Turning OFF**
Press  key until **red** LED turns on.

Power Supply

AC Adapter



DC Input AC Input

AC operation

- Input power : AC100-240V, 50-60Hz
- Use only supplied AC power cord.
- Connect to ground with ground terminal of AC power cord.
- When using a AC power generator, check output voltage periodically with a circuit tester.

DC operation

- Input power : DC12V
- Use only supplied DC power cord.

Battery Pack


How to recharge Battery Pack



Recharge by DC is also possible

- ◆ Connect AC adapter (ADC-18) and battery pack (BTR-09) with battery recharge cord (DCC-18).
- ◆ Do not stack battery pack on top of AC adapter while recharging.
- ◆ Recharging temperature : 0 ~ 40°C (32 ~ 104°F)

How to check remaining capacity




Note

Confirm power saving function is working when using battery pack

Cleaning before Splice Operation

V-grooves



- Clean bottom of V-groove with a thin cotton swab moistened with alcohol.
- Remove excess alcohol from V-grooves with a clean dry swab.
- Use a cleaved fiber end-face to dislodge.


Caution of cleaning

- Do not contact the electrode tips.
- Use only 99% or better purity of alcohol.

Fiber Clamp Chips



Objective Lens



When lens is dirty, clean it.

Fiber Cleaver

- Clean rubber pads.
- Clean rubber anvil.
- Clean blade.



Replace Electrodes

Electrodes


- When “Replace electrodes” message appears, or when the tip is damaged, replace electrodes.
- Execute [Replace Electrodes] in Maintenance Menu.
- Exchange for a new electrode the old electrode currently attached to equipment.
Use attached screw driver (SD-01).

Remove the electrode cover



Place the electrode cover

Loosen screws



Electrode holder

Tighten screws

Remove the old electrode



Install new electrode

- Load prepared fibers onto the splicer.
- Execute [Stabilized Electrodes]
- [Arc Calibration] is executed.

Solution of an Error

Error Message	Reason	Solution
Too Long Fiber	<ul style="list-style-type: none"> The fiber end-face is placed on the electrode centerline, or beyond it. The cleave length (bare fiber part) is too long Dust or dirt is on the objective lens. 	<ul style="list-style-type: none"> Press [RESET], and set the fiber end-face between the electrode centerline and the V-groove edge. Confirm the setting position of the stripped fiber end on the fiber cleaver. Check the cleave length. Execute the [Dust Check]. Clean the lens when dust or dirt exists.
Too Dusty Fiber	<ul style="list-style-type: none"> Dust or dirt is on the fiber surface. Dust or dirt is on the objective lens. [Cleaning Arc] time is too short or "OFF." 	<ul style="list-style-type: none"> Completely prepare the fiber again (strip, clean and cleave). Execute the [Dust Check]. Clean the lens if dust or dirt exists. Set the [Cleaning Arc] time to "150ms." When splicing carbon coated fibers, set to "200ms."
ZL/ZR Motor Overrun	<ul style="list-style-type: none"> The fiber is set too far back and does not reach the splice point. The fiber is not set correctly at the bottom of the V-groove. The fiber is not located in the Camera's field of view. The cleave length (bare fiber part) is too short. 	<ul style="list-style-type: none"> Press [RESET], re-position the fiber again with the end-face closer to the electrodes. Press [RESET], and set the fiber again to seat it correctly at the bottom of the V-groove. Confirm the setting position of the stripped fiber end on the fiber cleaver. Check the cleave length.
Large Cleave Angle	<ul style="list-style-type: none"> Bad fiber end-face. [Cleave Limit] is set too low 	<ul style="list-style-type: none"> Check the condition of the fiber cleaver. If the blade is worn, rotate the blade to a new position. Increase the [Cleave Limit] to an adequate limit.
Cleave Shape NG	<ul style="list-style-type: none"> Bad fiber end-face. 	<ul style="list-style-type: none"> Check the condition of the fiber cleaver. If the blade is worn, rotate the blade to a new position.

Contact Address

Fujikura Ltd.	1-5-1 Kiba, Koto-ku, Tokyo 135-8512 Japan Phone : +81-3-5606-1164 Fax : +81-3-5606-1534 https://www.fusionsplicer.fujikura.com
Fujikura (CHINA) Co., Ltd.	7 th Floor, Hang Seng Bank Tower 1000Lujiazui Ring Road,Pudong New Area ShanghaiZIP200120,China Phone : +86-21-6841-3636 Fax : +86-21-6841-2070 http://www.fujikura.com.cn
Fujikura Asia Ltd.	438A Alexandra Road,Block A Alexandra Technopark #08-03,Singapore 119967 Phone : +65-6278-8955 Fax : +65-6273-7705 http://www.fujikura.com.sg
Fujikura Europe Ltd.	C51 Barwell Business Park, Leatherhead Road, Chessington, Surrey KT9 2NY. UK. Phone : +44-20-8240-2000 Fax : +44-20-8240-2010 http://www.fujikura.co.uk
AFL	260 Parkway East, Duncan, SC 29334 USA Phone : +1-800-235-3423 Fax : +1-800 -926-0007 http://www.AFLglobal.com
Authorized Splicer Distributor	

